

# 1993 Chevrolet Caprice Classic LS

## SYSTEM WIRING DIAGRAMS

### Fig. 15: Starting Circuit

